


ASSEMBLY INSTRUCTIONS



Farlane Large Chandelier

Item # TOB 5017

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING*SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.**

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT. DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

NOTE: CAREFULLY UNPACK EACH PIECE IN TOP LAYER OF PACKING PRIOR TO REMOVING. RETAIN ALL PACKING MATERIAL UNTIL INSPECTION AND INSTALLATION ARE FINAL.

1. Carefully remove all parts from the box.
2. Remove the mounting plate (B) from the canopy (D) by unscrewing the canopy screws (E).
3. Install the mounting plate (B) to junction box and secure with the mounting screws (C).
4. Weave the fixture wires through the rods (H), (G), (F) and canopy (D).
5. Thread the rod (H) to the fixture body (J) and thread the rod (G) to rod (H), then thread rod (F) to the rod (G).
6. Screw the canopy (D) to the rod (F).
7. Measure the wires then cut, be certain to leave enough length to connect the wires in the junction box.
8. Strip the insulation on the fixture wires about 5/8".
9. Wrap the fixture ground wire to the green ground screw on the mounting plate (B) and secure, then connect to ground wire in the junction box using wire nut (A).
IT IS IMPERATIVE THAT THIS FIXTURE BE GROUNDED.

10. Connect the fixture ribbed wire (no marking) to the junction box neutral wire with the wire nut (A).

11. Connect the fixture smooth wire (with marking) to the junction box hot wire with the wire nut (A).

DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OTHERWISE SAFETY WILL BE COMPROMISED.

12. Carefully tuck the wire connections into the junction box.
13. Install the canopy (D) to the mounting plate (B) and secure with the canopy screws (E).
14. Install the finial (K) to the bottom of fixture body (J).
15. Insert light bulbs (not included) into sockets.
16. Clip the shades (I) onto the bulbs.
17. Installation is complete, turn on power at fuse or circuit breaker.

***Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.

VISUAL COMFORT

